



Mouse Anti-SmD1 ELISA Kit

Catalog Number EA-5209

(For Research Use Only)

Introduction

Antibodies against the Sm antigens of the small nuclear ribonucleoproteins (snRNPs) are a very specific marker for the diagnosis of systemic lupus erythematosus (SLE). Antibodies against the Sm proteins are found in 20-30% of SLE patients. Anti-Sm antibodies are observed at a high titer in the active period of SLE and at a low titer in the non-active period. Antibodies directed against Sm proteins as well as DNA found in sera from patients with SLE have been included as one of the American College of Rheumatology classification criteria for SLE. Sm antigen is now known to be consisted of at least nine different polypeptides. Anti-Sm antibodies are predominantly directed against the SmD1 protein of the snRNP complex.

Principle of the assay

Anti-SmD1 ELISA kit measures anti-Sm antibodies in the serum. It is based on the principle of a solid phase enzyme-linked immunosorbent assay. The assay utilizes the SmD1 protein for immobilization on the microtiter wells and anti-mouse IgG antibody conjugated to horseradish peroxidase (HRP) for detection. The test sample is allowed to react simultaneously with the two components, resulting in Anti-Sm antibodies being sandwiched between the solid phase and enzyme-linked antibodies. After incubation, the wells are washed to remove unbound-labeled antibodies. A HRP substrate, TMB, is added to result in the development of a blue color. The color development is then stopped with the addition of Stop Solution changing the color to yellow. The concentration of anti-Sm antibody is directly proportional to the color intensity of the test sample. Absorbance is measured spectrophotometrically at 450 nm.




Diagram of ELISA

Materials provided with the kit

- 8x12 96-well plate coated with SmD1 (4°C).
- Anti-mouse IgG antibody conjugated to HRP (4°C).
- 1X Diluent buffer (4°C).
- 5X Assay Wash buffer (4°C).
- Substrate (4°C).
- Stop Solution (4°C)

Material required but not provided

- Microplate reader capable of measuring absorbance at 450 nm
- Shaker

Reagent preparation before starting experiment

- Dilute the 5x Assay wash buffer to 1x buffer
40ml 5x Assay wash buffer
160ml ddH₂O
- Dilute 1000 times of anti-mouse IgG antibody conjugated to HRP with 1X Diluent buffer.
- Avoid contact of Substrate and Stop Solution with any metal surfaces.
- Important Note: Before beginning your experiment, quickly take 50µL of the Substrate and check to make sure it's clear. **If its color has changed to dark blue, do not begin the experiment and contact us immediately.**

SAMPLE COLLECTION AND STORAGE

Serum

Use a serum separator tube and allow samples to clot for 30 minutes before centrifugation for 15 minutes at 1000 g. Remove serum and assay immediately or aliquot and store samples at -20° C. Avoid repeated freeze-thaw cycles.

Plasma

Collect plasma using citrate, EDTA, or heparin as an anticoagulant. Centrifuge for 15 minutes at 1000 g within 30 minutes of collection. Assay immediately or aliquot and store samples at -20° C. Avoid repeated freeze-thaw cycles.

Assay procedure

1. Take the desired number of well strips from the plate. Make sure the rest of strips are well sealed.
2. Add 100 µl of diluted samples (1:100 diluted with 1X Diluent Buffer) per well and incubate for 1 hour at room temperature with gentle shaking. *Note: We recommend having a blank condition. For the blank, add only 1x Diluent buffer to the well.
3. Aspirate each well and wash by adding 200µl of 1X Assay wash buffer. Repeat the process twice for a total of three washes. Completely remove liquid at each wash by firmly tapping the plate against clean paper towels.
4. Add 100µl of diluted anti-mouse IgG antibody conjugated to HRP to each well and incubate for 30 minutes at room temperature with gentle shaking.
5. Repeat the aspiration/wash as in step 3.
6. Before adding substrate, check to make sure it is clear. **If the substrate is already blue, please leave the wash buffer in the wells, seal and store the plate at 4°C, and contact us immediately.**
7. Add 100µl of Substrate to each well and incubate for 20-45 minutes.
*Note: Positive control will turn blue. Samples can be incubated longer for a stronger signal.
8. Add 50µl of Stop solution to each well. The color in the wells should change from blue to yellow.
9. Determine the optical density of each well with a microplate reader at 450 nm within 30 minutes.